

# Buffered USB2.0 Monochrome 5MP CMOS Cameras (12-bit)

(Part Numbers: BTN-B050-U and BTE-B050-U)

## FEATURES

- Built-in frame buffer (3 frames at 8 bit and 2 frames at 12bit, with full resolution)
- Switchable between 8 bit and 12 bit
- Support simultaneous image capturing from multiple cameras
- 4-pin GPIOs
- Higher sensitivity than color cameras especially in IR
- 2,592 x 1,944 active imaging pixels
- High-speed USB2.0 (480Mb/s)
- Digital output, no need for frame grabber
- Full-featured SDK
- DirectShow and TWAIN driver
- Linux driver available
- USB command set for non-Windows-based applications
- External and Software trigger
- Strobe output for external flash
- ROI & pixel skipping/binning
- No need for external power supply
- OEM versions available

## APPLICATIONS

- Digital microscopy
- Machine vision
- Medical imaging
- Semiconductor equipment
- Test instruments
- Document scanners
- 2D barcode readers
- Web camera and security Video
- High-quality ID photos



## PRODUCT DESCRIPTION

Mightex USB2.0 cameras with frame buffers are optimized for machine-vision applications, and they can be also used for a wide variety of applications (such as industrial inspections, digital microscopy and medical imaging) which require good quality cameras that are easy to use and cost-effective. These cameras have built-in frame buffers, external trigger-in, strobe-out, and a powerful camera engine that supports multiple cameras. Monochrome cameras often exhibit 20% higher spatial resolution than their color counterparts because no pixel interpolation is necessary. Since there is no Bayer color filter on the sensor, monochrome cameras are more sensitive than color sensors, especially in near IR and UV regions. Frame rate can be as high as 6 fps in full resolution and up to 150 fps using ROI mode. A user-friendly GUI based application software and an SDK are provided for custom software development. In addition, a DirectShow driver and a TWAIN driver are available to easily link the cameras with users' applications. A USB command set protocol and a Linux driver are also provided for non-Windows based applications.

## PERFORMANCE SPECIFICATIONS

Parameters	BTN-B050-U	BTE-B050-U	Unit
Board-level / enclosed	Board-level	Enclosed	
Number of GPIOs	4	4	
Resolution	2,592 x 1,944 monochrome		
Bit	8/12 (switchable)		bits
CMOS Chip	Micron MT9P031, rolling shutter		
Pixel Size	2.2 x 2.2		µm
Scanning System	Progressive		
Dynamic Range	70		dB
Sensor SNR	38		dB
Gray Level	8		bit
Responsivity	1.4		V/lux-sec
Frame Rates* (@48MHz Clock)	3 @2,592 x 1,944 5 @2,048 x 1,536 7 @1,600 x 1,200 12 @1,280 x 1,024 21 @1,024 x 768 33 @800 x 600 43 @752 x 480 51 @640 x 480 100 @320 x 240		fps
Sub Resolutions	Support arbitrary ROI (Nx, Ny), with Nx and Ny multiples of 4		
Shutter Speed (Exposure time)	0.05 ~ 750		ms
Hardware Gains	1x ~ 16x		
Trigger Mode	With external trigger**		
Strobe Out	Yes		
Lens Mount	C- mount or CS-mount (M12.5-mount or custom-defined lens mount supported)		
Built-in Filters	IR-cut (factory standard), no filter, or IR-pass		
Power Consumption	< 1.8		W
Dimension	51 x 51 x 29 (CS-mount) 51 x 51 x 34 (C-mount)	58 x 58 x 34 (CS-mount) 58 x 58 x 39 (C-mount)	mm
Weight (excluding lens)	80	150	g

\* The actual achievable frame rate depends on exposure time, as well as available resources of PC system.

\*\* Part number of the trigger cable for external trigger : ACC-CAM-DIN8

# Buffered USB2.0 Monochrome 5MP CMOS Cameras (12-bit)

(Part Numbers: BTN-B050-U and BTE-B050-U)


## OPERATION CONDITION

Operating Temperature Range: 0°C ~ 45°C  
Storage Temperature Range: -25°C ~ 85°C  
Relative Humidity, Non-condensing: 5% ~ 95%

## RECOMMENDED SYSTEM CONFIGURATION

Processor: Pentium III 900 MHz or better, or a compatible processor  
Operating System: Windows 2000, XP, Vista, Windows 7 and 8  
RAM: 256MB or greater  
Hard Disk Space: 30MB for software installation, plus additional space for storing captured images  
USB2.0 Host Controller: Intel integrated host controller (recommended)

## EXAMPLE OF GRAPHICAL USER INTERFACE






# Buffered USB2.0 Monochrome 5MP CMOS Cameras (12-bit)

(Part Numbers: BTN-B050-U and BTE-B050-U)

## WHAT'S IN A C-MOUNT CAMERA?



A C-mount camera is composed of a CS-mount camera and a CS-to-C-mount adapter. The latter is essentially a 5mm thick threaded ring.

With a world-class OEM design team, Mightex offers a broad range of customized solutions in order to meet individual customer's unique requirements. Please call 1-416-840 4991 or email [sales@mightex.com](mailto:sales@mightex.com) for details.